



Adjusting paddle latches on H, V, US & UST Series toolboxes

Adjust the slam-style paddle latch on an H, V, US or UST toolbox when...

1. The door will not shut all the way.
2. The paddle is loose in the closed position, but tight in the open position.
3. The door closes all the way, but is not sealing tightly.

Using a crescent wrench or pair of pliers, (being careful not to bend the channel that the striker is welded to) bend the inner ear on the striker (elongated channel welded to the box) slightly toward the rear of the box to tighten the closure of the door, or slightly toward the door opening to loosen the door pressure. Apply lithium grease to the striker and moving parts of the paddle latch.



Tighten

Loosen

The outer ear on the striker is designed as a “safety catch” to keep the door from opening. Apply lithium grease to the striker and moving parts of the paddle latch.

For further assistance, contact technical support at RKI, Inc.