



Adjusting paddle latches on ST or STS Series toolboxes

Adjust the paddle latches on an ST or STS Series toolbox when...

1. There is more than ¼" of play in the lid.
2. The lid is too tight.

Open the lid and loosen the nut on the striker plate bolt.



Move the striker very slightly down to tighten the lid and up to loosen the lid.



Tighten the nut on the striker plate bolt. Apply lithium grease to the striker and moving parts of the paddle latch.

For further assistance, contact technical support at RKI, Inc.